

USER MANUAL



Security Precautions

In order to have a proper and safe use of the headset, please read this user manual in detail and save it.


Be aware of the following guidelines when using your headset:

1. You should adjust the volume carefully when using the headset to prevent hearing damage.
2. Please stop using the headset in potentially hazardous situations to ensure your safety.
3. Please avoid using the headset to listen to music, make or receive calls which may cause a distraction while driving.
4. Put this product and its accessories somewhere out of the reach of children, to avoid a fatal danger caused by inappropriate use.
5. You should keep water from entering the headset, which may cause damage to the sound quality or the headset.
6. You should avoid turning the volume so high that you can't hear anything around you. If you feel a tinnitus or the volume is too high, please reduce the volume.
7. Stop using the headset if you feel obvious discomfort, irritation or have other adverse reactions.
8. The headset should not be stored or used at temperatures below -15°C (5°F) or above 55°C (131°F) which may shorten headset or battery life

*** 2 ***

Overview of Headset

Overview of BTE05 Bluetooth stereo headset:



Charger and battery

1. Before charging, make sure the headset has been switched off.
2. Plug USB cable into the charging port of headset, plug the other side of USB cable into the USB charger or other charging device. Charging will start and the red light remains bright on the headset.
3. Charging time of headset takes approximately up to 1.5-2hours, the red light will turn to blue when fully charged.

*** 3 ***

Overview of Headset

Warning: You must use the original cable to charge the Bluetooth headset, otherwise it may damage the headset. Thus, voltage of the charger must be 5V, electric current exceed 100mA, and the battery must be fully charged in order to prevent damage to the headset, please do not remove the battery.

Power on:

- Keep pressing the MF button until blue light blinks.

Pairing Mode:

- Keep pressing the MF button until blue and red lights blink alternately

Switch off:

- Keep pressing the MF button until red light blinks and goes out.

Pair your headset with your cell phone:

1. Keep the distance between the headset and cell phone (or other devices being connected) within 1 meter. The closer the better.
2. Keep pressing the MF button until the blue and red lights blink alternately.
3. Initiate Bluetooth function of cell phone (or other device being connected). Then 'X5' will be shown on your phone.
4. Select 'X5' (some cell phones need you to input the PIN '0000' as password) and the headset will automatically connect with your cell phone, the blue light begins to blink. Attention: Generally, there is 120 seconds maximum to pair the headset with your cell phone, or the Bluetooth pairing mode will stop when the lights goes out. Please retry steps 1 to 4 to pair again if your operation doesn't work.

*** 4 ***

Overview of Headset

To disconnect the headset with your cell phone:

- Turn off the Bluetooth function of your cell phone.
- Or keep pressing the MF button until the red light goes out, to switch off the headset.
- Or take the headset from the cell phone to more than 10m (30ft) away.

To reconnect the paired headset with your mobile phone:

1. Keep the distance of the headset and cell phone (or other devices being connected) within 1 meter. The closer the better.

2. Switch on the headset, and the headset will enter into reconnection mode when the blue light blinks.

3. Switch on the Bluetooth search function in your cell phone or other devices being connected. Then the headset will automatically reconnect with the mobile phone which has connected last time

Answer incoming call:

- When there is an incoming call, press the MF button once to answer the call, or use your cell phone to answer it.

Reject a call:

- When there is an incoming call, double click MF button to reject call, or use your cell phone to reject the call.

Hang up a call:

- Press the MF button once or use your cell phone to hang up your call.

*** 5 ***

FAQ

Last call redialling:

- In standby mode, double-click the MF button to redial your last call.

Music Play/Pause:

- Press MF button once to play/pause music.

Volume adjustment/Music selection:

- Press Vol(+) and Vol(-) once to adjust volume, keep pressing the Vol(+) and Vol(-) to select previous track or next track.

FAQ

1.X5 Headset cannot pair with Cell phone?

Ans: Please check whether your headset is in pairing mode or reconnection mode. Please check your device's Bluetooth menu and delete/pair the headset and reconnect the headset again as before.

2.X5 headset cannot be switched on?

Ans: Please check the battery status of your headset.

3.Can I change the battery for the headset?

Ans: The headset use a built-in non-removable Li-Polymer battery, it cannot be removed.

4.Can I use headset while driving?

Ans: For safety reason, we strongly recommend not to use over-ear headset to avoid distraction while driving.

5.X5 Headset has disconnected with your cell phone within 10 meters?

Ans: Please check whether your headset is in pairing mode or reconnection mode which may interfere with the Bluetooth connection. Bluetooth is a radio technology which is sensitive to objects between the headset and the connected device.

6. I cannot hear a sound from your computer or cell phone?

Ans: Please check whether the output channel of your computer is Bluetooth, that the audio driver and playback function of your computer support A2DP profile, and the headset is connected with the correct channel of your computer.

7. I cannot use the headset to control the volume, to select a track or APP of my cell phone?

Ans: The Software settings of the APP may vary and lead to some functions of the APP not controllable by the headset.

*** 6 ***

Specification

Specification:

- Bluetooth version: V4.1
- Frequency range: 2.4GHz – 2.48GHz
- Operating distance: up to 10M
- Standby time: up to 180hrs
- Talking/music-playing time: about 6-7 hours
- Charging time: about 2 hours
- Frequency response: 20V-22KHz
- Operating temperature:-10°C-50°C

Technical specifications are subject to change without notice, we apologize for any inconvenience.

*** 7 ***